



### ASSEMBLY INSTRUCTIONS – CURIO CABINET



Your kit will come as flat pack pieces. You can paint the parts before assembly but avoid getting any in the joints or assembly will be difficult. Doing a “dry run” first (no glue!) can help with knowing what should go where! Always work with good sides facing out for best fit.



Assemble the 4 base plinth pieces making sure the notches all face up. Use ample glue to ensure a good seal when gluing up your kit and wipe up any oozes with a damp cloth before it dries.



Slot the 2 shelf pieces into the side pieces of the cabinet – make sure the straight edges of each piece all face the same way so that the notches are ready to slot in the back panel.



The back panel should slot in quite comfortably. Attach the base piece of the cabinet (this piece has one edge with no slots).



You can then slot in the base plinth that you assembled earlier. The doors can be used with or without panels, depending on whether you wish to see inside the curio cabinet when the doors are closed.



Slot the doors into the base of the cabinet before you put the top on!



Attach the top of the cabinet (this is the piece with 2 slots at the front ready for the decorative top flourish) and that's it! We hope you've enjoyed putting your kit together.